# HIKROBOT

# GigE Area Scan Camera

User Manual

# **Legal Information**

#### **User Manual**

© 2020 Hangzhou Hikrobot Technology Co., Ltd. All rights reserved.

#### **About This Manual**

The Manual includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of this Manual at the Hikrobot website (https://en.hikrobotics.com/).

Please use this Manual with the guidance and assistance of professionals trained in supporting the Product.

#### **Trademarks**

**HIKROBOT** and other Hikrobot's trademarks and logos are the properties of Hikrobot in various jurisdictions. Other trademarks and logos mentioned are the properties of their respective owners.

#### Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS MANUAL AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKROBOT MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKROBOT BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKROBOT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.

YOU ACKNOWLEDGE THAT THE NATURE OF INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKROBOT SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKROBOT WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS.

YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.

THE PERFORMANCE DATA IN THIS PUBLICATION IS BASED ON HIKROBOT'S INTERNAL RESEARCH/EVALUATION. ACTUAL DATA MAY VARY DEPENDING ON SPECIFIC CONFIGURATIONS AND OPERATING CONDITIONS AND HIKROBOT SHALL NOT BEAR THE CONSEQUENCES ARISING THEREFROM. IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATER PREVAILS.

# **Regulatory Information**

#### **FCC Information**

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**FCC compliance:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

#### **FCC Conditions**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired operation.

### **EU Conformity Statement**

This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the EMC Directive 2014/30/EU, LVD Directive 2014/35/EU, the RoHS Directive 2015/863/EU amending 2011/65/EU.



2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recyclethis.info

# **Symbol Convention**

The symbols that may be found in this document are defined as follows.

Symbol	Description
i NOTE	Provides additional information to emphasize or supplement important points of the main text.
MARNING	Indicates a potentially hazardous situation, which if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.
A DANGER	Indicates a hazard with a high level of risk, which if not avoided, will result in death or serious injury.

# Available Model

This manual is applicable to the GigE Area Scan Camera.

# Safety Instructions

These instructions are intended to ensure that the user can use the device correctly to avoid danger or property loss.

### **Laws and Regulations**

The device should be used in compliance with local laws, electrical safety regulations, and fire prevention regulations.

### **Power Supply**

- When wiring or dismounting, make sure that the device power is cut off, and do not operate under electrification.
- Avoid contact with exposed circuit. When the device is powered on, avoid contact with exposed junctions and parts.
- Use the power adapter provided by the regular manufacturer.
- Do not connect multiple devices to one power adapter, to avoid over-heating or fire hazards caused by overload.
- Make sure the plug is properly connected to the power socket.

### **Transportation**

- The device contains precision optical components and electronic components. During transportation, storage and installation, incorrect operations like heavy pressure and violent vibration should be avoided. Otherwise, the device may be damaged.
- Avoid sudden collision, and pack the device with the accompanied carton and cushioning material or similar package.

### **Using Environment**

- In order to reduce the risk of fire or electric shock, do not let the device get wet or damp.
- Do not drop objects onto the device and avoid vigorous vibration.
- Keep the device away from magnetic interference.
- Do not use the device in extremely heat, extremely cold, dusty environment, corrosive environment or high humidity environment.
- Do not aim the device lens at objects of strong light, such as the sun and incandescent lamp.
   Otherwise, the lens may be damaged.
- The device should be stored in dry environment without corrosive gas. Avoid placing the
  device in direct sunlight and poorly ventilated locations, or near heat sources such as heater or
  heating (ignoring this warning may lead to fire hazards).
- Do not operate in explosive environment.
- Keep the surrounding area well ventilated to avoid heat accumulation. Do not contact the radiator directly to avoid scald.

#### **Electrostatic Protection**

- Remove all conductive objects (such as jewelry, watch, etc.) on the device body before touching the device, and touch the grounding metal bracket by hand to release the static electricity.
- It is suggested to wear anti-static suit to prevent damage to the equipment caused by static electricity.

- When installing or maintaining the device, wear anti-static wristband or anti-static gloves.
   Make sure that the wristband is tightly attached to the skin and is reliably grounded.
- It is forbidden to touch exposed circuit boards with bare hands. Static electricity generated by human body may damage electrostatic sensitive components on circuit boards.
- When touching electrostatic sensitive components or devices, proper grounding measures must be taken.
- Put electrostatic sensitive components into anti-static bags for protection.
- It is suggested to place humidifier in dry environment to maintain suitable humidity and reduce static electricity generation.

#### Maintenance

- If the device is not working properly, contact the store or the nearest service center. Do not disassemble or modify the device in any way. (The company does not bear any liability for any problem arising from unauthorized modification or maintenance).
- Properly preserve all the original packaging materials of the device so that when problems arise, the device can be packed with packaging materials and sent to the agent or returned to the manufacturer for processing. The company does not bear any liability for accidental damage during transportation caused by non-original packaging.
- This device is a precision electronic device, no components can be maintained by user, do not disassemble the device arbitrarily.

### Cleaning

Do not touch the image sensor directly. If the sensor needs to be cleaned, use a clean rag and wet it with alcohol, then gently wipe off the dirt; if the device is not in use, cover the image sensor with dust cover for protection.

#### Installation

Do not install the device on vibrating surface or places that are vulnerable to impact.

## **Personnel Requirement**

Quality requirements for installation and maintenance personnel: qualification certificate or working experience in weak current system installation and maintenance, and relevant working experience and qualifications. Besides, the personnel must possess the following knowledge and operation skills:

- The basic knowledge and operation skills of low voltage wiring and low voltage electronic circuit connection.
- The ability to comprehend the contents of this manual.

#### **Contact Information**

Hangzhou Hikrobot Technology Co., Ltd.

No. 399 Danfeng Road, Binjiang District, Hangzhou, 310051, China

E-mail: tech support@hikrobotics.com

Website: en.hikrobotics.com

# **Table of Contents**

Chapter 1 Overview	1
1.1 Introduction	1
1.2 Key Feature	1
Chapter 2 Appearance	2
Chapter 3 Interface and Indicator	5
3.1 Interface Description	5
3.2 Indicator Description	7
Chapter 4 Camera Installation	8
4.1 Installation Preparation	8
4.2 Install Camera	8
Chapter 5 Camera Connection	9
5.1 Install MVS Client	9
5.2 Turn off Firewall	10
5.3 Set PC Network	11
5.4 Set Camera Network	12
5.5 Connect Camera to Client Software	13
Chapter 6 Client Software Layout	14
Chapter 7 Camera Features	17
7.1 Global Shutter	17
7.2 Rolling Shutter	17
7.3 Sensor Shutter Mode	18
7.4 Non-Overlap Exposure and Overlap Exposure	19
7.4.1 Non-Overlap Exposure	19
7.4.2 Overlap Exposure	20
Chapter 8 Image Acquisition	21
8.1 Set Frame Rate	21
8.2 Set Acquisition Mode	22
8.3 Set Trigger Mode	22
8.4 External Trigger Mode	23
8.4.1 Set External Trigger Source	23
8.4.2 Set Software Trigger	24
8.4.3 Set Hardware Trigger	25

	8.4.4 Set Counter Trigger	26
	8.4.5 Set Action Command Trigger	27
	8.4.6 Set Anyway Trigger	28
	8.5 Trigger Related Parameters	28
	8.5.1 Set Burst Frame Count	29
	8.5.2 Set Trigger Delay	30
	8.5.3 Set Trigger Cache Enable	30
	8.5.4 Set Trigger Activation	
	8.5.5 Set Trigger Debouncer	32
	8.6 Set Event Control	33
	8.7 Set Action Command	35
Chapt	er 9 I/O Output	37
	9.1 Select Output Signal	37
	9.2 Set Output Signal	37
	9.2.1 Enable Level Inverter	37
	9.2.2 Enable Strobe Signal	38
Chapt	er 10 I/O Electrical Feature and Wiring	42
	10.1 I/O Electrical Feature	42
	10.1.1 Line 0 Opto-isolated Input Circuit	42
	10.1.2 Line 1 Opto-isolated Output Circuit	43
	10.1.3 Line 2 Bi-direction I/O Circuit	44
	10.2 I/O Wiring	47
	10.2.1 Line 0 Wiring	47
	10.2.2 Line 1 Wiring	48
	10.2.3 Line 2 Wiring	49
Chapt	er 11 Image Parameter	52
	11.1 View Resolution	52
	11.2 Set ROI	52
	11.3 Set Image Reverse	53
	11.4 Set Pixel Format	54
	11.5 Set Test Pattern	55
	11.6 Set Binning	58
	11.7 Set Decimation	58
	11.8 Set Exposure Time Mode	59
	11 0 Sat Exposure Auto	50

# GigE Area Scan Camera • User Manual

	11.10 Set HDR	60
	11.11 Set Gain	61
	11.11.1 Set Analog Gain	61
	11.11.2 Set Digital Gain	62
	11.12 Set Brightness	63
	11.13 Set Black Level	64
	11.14 Set White Balance	64
	11.15 Set Gamma Correction	65
	11.16 Set Sharpness	67
	11.17 Set Channel Correct Mode	67
	11.18 Set AOI	68
	11.19 Set Color Transformation Control	68
	11.20 Set Hue and Saturation	69
	11.21 Set LUT	70
	11.22 Set Shading Correction	70
Chapt	ter 12 Other Functions	72
	12.1 Device Control	72
	12.2 Embedded Information in Image	74
	12.3 Set Multicast	76
	12.4 File Access Control	79
	12.5 Transport Layer Control	80
	12.6 Set Fan	84
	12.7 Save and Load User Set	84
	12.8 Update Firmware	86
Chapt	ter 13 Trouble Shooting	88
-	ter 14 Revision History	
-	ndix A Camera Parameter Index	90
ADDE	noix A Camera Parameter Index	90

# Chapter 1 Overview

### 1.1 Introduction

The GigE area scan camera uses the GigE interface to transmit non-compressed images in real time, and it acquires images and sets parameters via the client software or SDK. The GigE area scan camera is applicable to the automated optical inspection (AOI) for the surface mounted technology and the printed circuit board, electronic semiconductor, factory automation, logistics industry, etc.

# 1.2 Key Feature

- Supports auto and manual adjustment for gain, exposure time and white balance, manual adjustment for Look-Up Table (LUT), Gamma correction, etc.
- Adopts the image interpolation algorithm for the color reproduction.
- Supports the hardware trigger, software trigger, free run, etc.
- Adopts GigE interface and max. transmission distance of 100 meters without relay.
- Compatible with the GigE Vision Protocol, the GenlCam Standard, and the third-party software based on the protocol and standard.

# i NOTE

- The camera functions may differ by camera models.
- For specific camera functions, refer to the camera's user manual.

# Chapter 2 Appearance

# **i** NOTE

Appearances here are for reference only. Refer to the camera's specification for detailed dimension information.






Figure 2-2 Appearance (Type II)










Figure 2-3 Appearance (Type III)










Figure 2-4 Appearance (Type IV)










Figure 2-5 Appearance (Type V)










Figure 2-6 Appearance (Type VI)








Figure 2-7 Appearance (Type VII)

Table 2-1 Description

No.	Name	Description
1	Lens Mount	It is used to install the lens.
2	Screw Hole	It is used to fix the camera to the installation position.
3	Gigabit Ethernet Interface	It refers to the gigabit Ethernet interface for transmitting data.
4	Screw Hole	It refers to the M2 screw hole for securing the network cable.
5	Power and I/O Interface	It refers to the power and I/O interface that provides power, input/output signal, serial port, etc.
6	LED Indicator	It indicates the camera's status.
7	Fan	It is used to cool the camera.

# Chapter 3 Interface and Indicator

# 3.1 Interface Description

There are 2 types of power and I/O interfaces, including 6-pin and 12-pin power and I/O interfaces. Read the followings to get pin definitions.




Figure 3-1 6-Pin Interface

Refer to the pin definitions and labels attached to the power and I/O cable to wire the device.

Table 3-1 Pin Definitions (6-Pin)

No.	Signal	I/O Signal Source	Description
1	DC_PWR		Camera power supply
2	OPTO_IN	Line 0+	Opto-isolated input
3	GPIO	Line 2+	Can be configured as input or output
4	OPTO_OUT	Line 1+	Opto-isolated output
5	OPTO_GND	Line 0/1-	Opto-isolated signal ground
6	GND	Line 2-	Camera power supply ground




Figure 3-2 12-Pin Interface

Refer to the pin definitions and labels attached to the power and I/O cable to wire the device.

Table 3-2 Pin Definitions (12-Pin)

No.	Signal	I/O Signal Source	Description			
1	GND	Line 2-	Camera power supply ground			
2	DC_PWR		Camera power supply			
3	Reserved					
4	Reserved					
5	GND_IO	GND_IO Line 0/1- Opto-isolated signal ground				
6	Reserved					
7	Reserved					
8	RS-232_RX RS-232 received data					
9	RS-232_TX		RS-232 transmitted data			
10	GPIO	Line 2+	Can be configured as input or output			
11	OPTO_OUT	Line 1+	Opto-isolated output			
12	OPTO_IN	Line 0+	Opto-isolated input			

# 3.2 Indicator Description

The camera indicator is used to display different camera status.

Table 3-3 Indicator Description

No.	Indicator Color	Status	Description
1	Red	Flashing very slowly	The camera wiring exception occurs.
2	Red	Solid	The camera exception occurs.
3	Blue	Flashing slowly	The camera is acquiring images in trigger mode.
4	Blue	Flashing rapidly	The camera is acquiring images normally.
5	Blue	Solid The camera is in idle status.	
6	Red and blue	Flash alternatively	The function of finding me is executed, or the firmware is updating.

# i NOTE

- When the indicator is flashing rapidly, flashing slowly, or flashing very slowly, its unlit interval is 0.2 s, 1 s, 2 s respectively.
- The indicator sometimes may show a purple color when red and blue colors flashing at the same time.

# **Chapter 4 Camera Installation**

# 4.1 Installation Preparation

You need to prepare following accessories before camera installation.

Table 4-1 Accessories

No.	Name	Quantity	Description
1	Power and I/O Cable	1	It refers to the 6-pin or 12-pin power and I/O cable. You need to purchase separately.
2	Network Cable	1	It refers to CAT-5e network cable or above. You need to purchase separately.
3	DC Power Supply	1	You should select suitable power adapter or switch power supply according to the camera power supply and consumption. You need to purchase separately.
4	Lens	1	It refers to the lens that matches with lens mount of the camera. You need to purchase separately.
5	Adapter Ring	1	If the lens you used does not match with lens mount of the camera, you need to use an adapter ring. You need to purchase separately.

### 4.2 Install Camera

#### Before you start

Make sure all the related devices are power-off during the installation.

- 1. Fix the camera to the installation position.
- 2. Install the lens to the camera.
- 3. Use a network cable to connect the camera with a switch or a network interface card.
- 4. Select a power supply method.
- Direct supply: Use the 6-pin or 12-pin power and I/O cable to connect the camera to a power adapter.
- PoE (Power over Ethernet): For the camera that supports PoE, use a network cable to connect the camera to a switch that supports PoE or a network interface card.

# **Chapter 5 Camera Connection**

Camera connection to the client software is required for camera's configuration and remote operations. This section introduces how to install the client software, set PC and camera network, connect the camera to the client software, etc.

### 5.1 Install MVS Client

MVS client software is used to connect the camera, set its parameters, etc.

# i NOTE

- The MVS client software is compatible with 32/64-bit Windows XP/7/10, 32/64-bit Linux, and 64-bit MacOS operating systems. Here we take Windows as an example.
- The graphic user interface may differ by different versions of the client software you use.
- You can download Windows version client software from en.hikrobotics.com. For other versions, you can mail to tech\_support@hikrobotics.com to get client software installation package.

- 1. Double click the MVS installation package.
- 2. Select the language.
- 3. Read and check **Terms of the License Agreement**.




Figure 5-1 Installation Interface

#### 4. Click Start Setup.




Figure 5-2 Default Settings

- 5. Keep default settings, and click Next.
- 6. Finish the installation according to the interface prompts.

### 5.2 Turn off Firewall

To ensure stable client running and image transmission, you are recommended turning off Windows firewall before using the client software.



For different Windows versions, the path name or interface may differ.

- 1. Go to Windows Firewall.
- Windows XP system: Click Start > Control Panel > Security Center > Windows Firewall.
- Windows 7 system: Click Start > Control Panel > Windows Firewall.
- Windows 10 system: Click Start > Control Panel > System and Security > Windows Defender Firewall.
- 2. Click Turn Windows Defender Firewall on or off on the left.
- 3. Select Turn off Windows Defender Firewall (not recommended).

V	Turn on Windows Defender Firewall
	Block all incoming connections, including those in the list of allowed apps
	Notify me when Windows Defender Firewall blocks a new app
×	Turn off Windows Defender Firewall (not recommended)

Figure 5-3 Windows Defender Firewall

4. Click OK.

#### 5.3 Set PC Network

To ensure stable image transmission and normal communication between the PC and the camera via client software, you need to set the PC network before using the client software.

**i** NOTE

For different Windows versions, the path name or interface may differ.

- 1. Go to PC network settings page: Start > Control Panel > Network and Internet > Network and Sharing Center > Change adapter settings.
- 2. Select NIC and set the IP obtainment mode.
  - Select **Obtain an IP address automatically** to get an IP address of the PC automatically.
  - Select Use the following IP address to set an IP address for the PC manually.
- 3. Set NIC property via the PC.
  - 1) Go to NIC settings page: **Control Panel > Hardware and Sound > Device Manager > Network Adapter**.
  - 2) Select corresponding network interface card, and click **Advanced**.
  - 3) Set **Jumbo Packet** value to 9014 Bytes, **Transmit Buffers** and **Receive Buffers** to 2048, **Interrupt Moderation Rate** to Extremum.
- 4. (Optional) Set NIC property via the MVS.
  - 1) Right click the Ethernet, and click NIC Settings.




Figure 5-4 NIC Settings

2) Enable Jumbo Frame, and set Receive Buffers and Transmit Buffers to 2048.




Figure 5-5 NIC Configurator



The max. value of receive buffers and transmit buffers may differ by network interface cards.

### 5.4 Set Camera Network

You can set and operate the camera in the client software only when the camera is in the same network segment with the PC where the client software is installed.

- 1. Double click the client software to run it.
- 2. Click in device list to search the device.

- 3. Select a device to be connected.
- 4. Right click the device, and click Modify IP.
- 5. Set the IP address of the device in the same network segment with the PC
- 6. Click OK.



Figure 5-6 Modify Device IP Address

### 5.5 Connect Camera to Client Software

Make sure your device IP address is in the same network segment with the PC where you installed the client software before connecting the device to it.

Double click the device name in device list, or click \textstyle to connect the device to the client.

# Chapter 6 Client Software Layout

After connecting to the camera, the client software can read the camera attributes and display them.




Figure 6-1 Main Window

# I NOTE

For specific main window of the client software, please refer to the actual one you got.

Table 6-1 Description of the Main Window

No.	Area Name	Description
1	Menu Bar	The menu bar displays function modules, including File, View, Settings, Tool, and Help.
2	Control Toolbar	The control toolbar provides quick operations for the device.
3	Device List Panel	This panel displays device list, and you can connect or disconnect device, modify device IP address, etc.
4	Device Information Panel	This panel displays the detailed device information.

No.	Area Name	Description	
5	Display Window	This area displays the acquisition images in real-time. You can click different icons to capture and save image, record, etc.	
6	Feature Panel	You can view and set features of the selected camera, and perform operations such as importing, exporting, and saving features.	

Click  $\blacksquare$  in the camera's feature panel to unfold the specific camera parameters, and set them according to actual demands.

I NOTE

The camera's attribute tree and parameters may differ by camera models.

Table 6-2 Description

Attribute	Description	
Device Control	You can view the device information, edit its name, reset the device, etc.	
Image Format Control	You can view and set the device's resolution, image reverse function, pixel format, region of interest, test pattern, etc.	
Acquisition Control	You can view and set the device's acquisition mode, frame rate, trigger mode, exposure time, etc.	
Analog Control	You can view and set the device's gain, black level, Gamma correction, sharpness, etc.	
Color Transformation Control	You can view and set the device's color transformation related parameters like hue and saturation.	
LUT Control	You can view the Look-Up Table (LUT), and set its index and value.	
Shading Correction	You can set shading correction to correct shade.	
Digital IO Control	You can set the different input and output signals.	
Action Control	You can view and set the device's action control related parameters.	
Counter And Timer Control	You can view and set the counter related parameters.	

Attribute	Description	
File Access Control	You can view and set the device's file access control related parameters.	
Event Control	You can view and set the device's event control related parameters to let the device generate an event and transmit a related event message to the computer.	
Chunk Data Control	You can view and set the device's chunk data control related parameters to generate supplementary image data and append that data to every image that you acquire.	
Transport Layer Control	You can view and set the parameters of the device's transport layer.	
User Set Control	You can save or load the device's parameters.	

# **Chapter 7 Camera Features**

### 7.1 Global Shutter

For camera that supports global shutter, its exposure starts and ends in each line simultaneously. After the exposure, data readout starts line by line. All pixels expose at the same time, then readout at different time, as shown below.




Figure 7-1 Global Shutter

# 7.2 Rolling Shutter

For cameras that support rolling shutter: as soon as the exposure ends, and the data readout starts simultaneously. After the whole action, the rest of rows start to expose and read out one by one. All pixels expose at the same time, then readout at different time, as shown below.




Figure 7-2 Rolling Shutter

#### 7.3 Sensor Shutter Mode

I NOTE

The sensor shutter mode may differ by camera models.

The sensor shutter mode allows you to set the operating mode of the camera's electronic shutter. The shutter mode refers to the way in which the image data is captured and processed.

In general, there are 3 sensor shutter modes, including **Global Reset**, **Rolling** and **Trigger Rolling**.

Global reset means that all of the sensor's pixels start exposing at the same time, but stop exposing at different time.




Figure 7-3 Global Reset

Rolling means that the camera exposes the pixel rows one after the other, and it supports sensor's pixels exposure and pixel data readout proceeding at the same time. While trigger rolling does not support that sensor's pixels exposure and pixel data readout proceed at the same time.

You can go to **Acquisition Control** > **Sensor Shutter Mode**, and select **Sensor Shutter Mode** according to actual demands.



Figure 7-4 Sensor Shutter Mode

**i** NOTE

Only when the **Trigger Mode** is **Off**, you can select **Rolling** as **Sensor Shutter Mode**.

### 7.4 Non-Overlap Exposure and Overlap Exposure

The process that camera captures one frame of image includes two stages, exposure and readout. According to the overlap relation between the exposure time and the readout time, cameras with different sensors can be divided into overlap exposure and non-overlap exposure.

### 7.4.1 Non-Overlap Exposure

After completing the current frame's exposure and readout, the next frame starts to expose and read out. This process is called non-overlap exposure. The non-overlap exposure's frame period is larger than the sum of the exposure time and the readout time, as shown below.

#### Non-overlap Exposure under Internal Trigger Mode




Figure 7-5 Internal Trigger Non-Overlap Exposure

#### Non-overlap Exposure under External Trigger Mode




Figure 7-6 External Trigger Non-Overlap Exposure

i NOTE

The camera will ignore the external signal in the readout section under this mode.

### 7.4.2 Overlap Exposure

Overlap exposure refers to the overlap between the current frame exposure and the previous frame readout. In other words, when the previous frame starts to read out, the current frame starts to expose simultaneously, as shown below.

#### Overlap Exposure under Internal Trigger Mode




Figure 7-7 Internal Trigger Overlap Exposure

#### Overlap Exposure under External Trigger Mode




Figure 7-8 External Trigger Overlap Exposure

I NOTE

The camera will ignore the external signal in the readout section under this mode.

# **Chapter 8 Image Acquisition**

#### 8.1 Set Frame Rate

Frame rate refers to the image number that is acquired by the camera per second. The higher frame rate, and shorter time used for image acquisition will be. The following 4 factors determines the camera's frame rate in real-time.

- Frame readout time: the frame readout time is related with camera's sensor performance and image height. The lower the image height and less the frame readout time, and the higher the frame rate will be.
- Exposure time: if the reciprocal of max. frame rate that the camera supports is t, and when the
  configured exposure time is larger than t, the less the exposure time, the higher the frame rate
  will be. When the configured exposure time is less than or equal to t, exposure time will not
  influence the frame rate.
- Bandwidth: the larger the bandwidth, the higher the frame rate will be.
- Pixel format: the more bytes pixel format occupy, the lower the frame rate will be.

Click **Acquisition Control** > **Acquisition Frame Rate**, enter **Acquisition Frame Rate** according to actual demands, and enable **Acquisition Frame Rate Control Enable**.




Figure 8-1 Set Frame Rate

# i NOTE

- If the current real-time frame rate is smaller than configured frame rate, the camera acquires images according to the real-time frame rate.
- If the current real-time frame rate is larger than configured frame rate, the camera acquires images according to the configured frame rate.

You can click **Acquisition Control** > **Resulting Frame Rate** to view the camera's resulting frame rate, as shown below.




Figure 8-2 Resulting Frame Rate

# 8.2 Set Acquisition Mode

The camera has 2 types of acquisition modes, including **SingleFrame** mode and **Continuous** mode.

- SingleFrame mode: When camera starts image acquisition, it acquires one image only, and then stops.
- Continuous mode: When camera starts image acquisition, it acquires images continuously.
   Real-time frame rate decides the acquisition frame number per second. You can stop camera image acquisition manually.

Click **Acquisition Control** > **Acquisition Mode**, and select **Continuous** or **SingleFrame** according to actual demands.




Figure 8-3 Set Acquisition Mode



The acquisition mode is **Continuous** by default.

# 8.3 Set Trigger Mode

The camera has 2 types of trigger mode, including internal trigger mode and external trigger mode.

- Internal trigger mode: The camera acquires images via its internal signals.
- External trigger mode: The camera acquires images via external signals. These signals can be software signal and hardware signal, including software trigger, hardware trigger, counter trigger, etc..

Click **Acquisition Control** > **Trigger Mode**, and select **Off** or **On** as **Trigger Mode** according to actual demands.




Figure 8-4 Set Trigger Mode



**Off** refers to the internal trigger mode, and **On** refers to the external trigger mode.

## 8.4 External Trigger Mode

## 8.4.1 Set External Trigger Source

There are 5 types of external trigger sources, including software trigger, hardware trigger, counter trigger, action command trigger, and anyway. Their principle and parameter setting are shown below.

Table 8-1 Principle and Parameter of External Trigger Mode

External Trigger Source	Parameter	Parameter Value	Principle
Software trigger	Acquisition Control > Trigger Source	Software	The software sends trigger signal to the camera via GigE interface to acquire images.
Hardware trigger	Acquisition Control > Trigger Source	Line 0, Line 2	External device connects camera via camera I/O interface. External device sends trigger signal to camera to acquire images.
Counter trigger	Acquisition Control >	Counter 0	The counter sends trigger

External Trigger Source	Parameter	Parameter Value	Principle
	Trigger Source		signal to the camera to acquire images.
Action command trigger	Acquisition Control > Trigger Source	Action 1	The action command sends trigger signal to the camera to acquire images.
Software trigger, hardware trigger and action command	Acquisition Control > Trigger Source	Anyway	Use software trigger, hardware trigger or action command to send trigger signal to the camera to acquire images.

Click **Acquisition Control** > **Trigger Source**, and select **Trigger Source** according to actual demands.




Figure 8-5 Set Trigger Source

# i NOTE

These 5 external trigger sources are valid only when the **Trigger Mode** is **On**.

# 8.4.2 Set Software Trigger

- 1. Click Acquisition Control > Trigger Selector.
- 2. Select Frame Burst Start as Trigger Selector, and On as Trigger Mode.
- 3. Select **Software** as **Trigger Source**, and click **Execute** in **Trigger Software** to send trigger commands.




Figure 8-6 Set Software Trigger

### 8.4.3 Set Hardware Trigger

The camera has 1 Opto-isolated input (Line 0), and 1 bi-directional I/O (Line 2) that can be configured as input signal, as shown below.

#### Steps:

- 1. Click **Digital IO Control**.
- 2. Select Line 2 as Line Selector, and Input as Line Mode to set line 2 as input signal.




Figure 8-7 Set Line2 as Input Signal

3. Select Line 0, or Line 2 as Trigger Source.




Figure 8-8 Set Hardware Trigger

### 8.4.4 Set Counter Trigger

The counter trigger provides frequency division to the external trigger signal. You can set counter trigger as shown below.

#### Steps:

- 1. Click Acquisition Control > Trigger Selector.
- 2. Select Frame Burst Start as Trigger Selector, and On as Trigger Mode.
- Select Counter 0 as Trigger Source.




Figure 8-9 Set Counter Trigger

When using counter as trigger source, you need to set relevant parameters under Counter And **Timer Control**. For specific parameter function and setting, please refer to the following table.

	Table 8-2 Description of Counter And Timer Control		
Parameter	Read/Write	Description	

Parameter	Read/Write	Description
Counter Selector	Read and write	It selects counter source. Counter 0 is available only at present.
Counter Event Source	Read and write	It selects the signal source of counter trigger. <b>Line 0</b> and <b>Line 2</b> are available. It is disabled by default.
Counter Reset Source	Read and write	It selects the signal source of resetting counter. <b>Software</b> is available only. It is disabled by default.
Counter Reset	Write is available under certain condition	It resets counter and it can be executed when selecting <b>Software</b> as <b>Counter Reset Source</b> .

Parameter	Read/Write	Description
Counter Value	Read and write	It is the counter value with the range of 1 to 1023.
Counter Current Value	Read only	It displays the number of executed external trigger.




Figure 8-10 Counter Trigger Parameters

### 8.4.5 Set Action Command Trigger

When you need to use the function of action commands, you should set action command trigger first.

- 1. Click Acquisition Control > Trigger Selector.
- 2. Select Frame Burst Start as Trigger Selector, and On as Trigger Mode.
- 3. Select **Action 1** as **Trigger Source**.




Figure 8-11 Set Action Command Trigger

I NOTE

For specific function of action commands, please refer to the section **Set Action Command** for details.

### 8.4.6 Set Anyway Trigger

When you need to use both hardware trigger and software trigger, you can set **Anyway** as **Trigger Source**.

#### Steps:

- 1. Click Acquisition Control > Trigger Selector.
- 2. Select Frame Burst Start as Trigger Selector, and On as Trigger Mode.
- 3. Select Anyway as Trigger Source.




Figure 8-12 Set Anyway Trigger

# 8.5 Trigger Related Parameters

Under external trigger mode, you can set burst frame count, trigger delay, trigger cache enable, trigger activation and trigger debouncer. Different trigger sources can set various trigger parameters, and their relation is shown below.

Table 8-3 Trigger Source and Trigger Parameter

Trigger Source Trigger Parameter	Software Trigger	Hardware Trigger	Counter Trigger	Action Command Trigger	Any Trigger
Burst Frame Count	V	V	٧	V	V
Trigger Delay	٧	٧	٧	٧	٧
Trigger Cache Enable	٧	٧	٧	٧	٧

Trigger Source Trigger Parameter	Software Trigger	Hardware Trigger	Counter Trigger	Action Command Trigger	Any Trigger
Trigger Activation	×	V	٧	×	٧
Trigger Debouncer	×	٧	٧	×	٧

#### 8.5.1 Set Burst Frame Count

Under external trigger mode, you can set burst frame count as shown below.

Click **Acquisition Control** > **Acquisition Burst Frame Count**, and enter **Acquisition Burst Frame Count** according to actual demands. Its range is from 1 to 1023.




Figure 8-13 Set Burst Frame Count

When **Acquisition Burst Frame Count** is 1, it is in single frame trigger mode. When **Acquisition Burst Frame Count** is larger than 1, it is in multi-frame trigger mode. If **Acquisition Burst Frame Count** is n and when inputting 1 trigger signal, the camera stops acquiring images after exposing n times and outputs n frame images. The sequence diagram of burst frame count is shown below.




Figure 8-14 Sequence Diagram of Burst Frame Count

### 8.5.2 Set Trigger Delay

From camera receiving signal and responding, this period is trigger delay. Its sequence diagram is shown below.




Figure 8-15 Signal Delay Sequence Diagram

You can set proper value in **Trigger Delay**, and its range is from 0  $\mu$ s to 16000000  $\mu$ s.




Figure 8-16 Set Trigger Delay

### 8.5.3 Set Trigger Cache Enable

The camera has the function of Trigger Cache Enable. During the triggering process, if the camera receives new trigger signal, it will save and process the signal if you enable this function. Trigger cache enable can save up to 2 trigger signals.

Click Acquisition Control > Trigger Cache Enable, and enable Trigger Cache Enable.




Figure 8-17 Enable Trigger Cache Enable

If the camera receives the 1st trigger signal first, and the camera receives the 2nd trigger signal during processing the 1st trigger signal.

- Disable Trigger Cache Enable: the 2nd trigger signal will be filtered without processing.
- Enable Trigger Cache Enable: the 2nd trigger signal will be saved.

If the 1st frame image's exposure time of the 2nd trigger signal is not earlier than the camera's last frame creation time of the 1st trigger signal, and then the 2nd trigger signal's 1st frame image is created normally.

If the 1st frame image's exposure time of the 2nd trigger signal is earlier than the camera's last frame creation time of the 1st trigger signal, and then the camera will delay this exposure time. Thus making sure this exposure time is not earlier than the camera's last frame creation time of the 1st trigger signal.

### 8.5.4 Set Trigger Activation

The camera supports trigger acquisition in the rising edge, falling edge, level high, or level low of the external signal. The principle and parameter of trigger activation are shown below.

Table 8-4 Trigger Activation Principle and Parameter

Trigger Activation	Parameter	Parameter Value	Principle
Rising edge	Acquisition Control > Trigger Activation	Rising Edge	Rising Edge refers to the rising edge of the trigger signal is valid, that is camera exposure and acquisition at the beginning of the rising edge of the trigger signal.
Falling edge	Acquisition Control > Trigger Activation	Falling Edge	Falling Edge refers to the falling edge of the trigger signal is valid, that is camera exposure

Trigger Activation	Parameter	Parameter Value	Principle
			and acquisition at the beginning of the falling edge of the trigger signal.
Level High	Acquisition Control > Trigger Activation	Level High	Level High refers to the level high of the trigger signal is valid. As long as trigger signal is in level high, the camera keeps exposure and acquisition status.
Level Low	Acquisition Control > Trigger Activation	Level Low	Level Low refers to the level low of the trigger signal is valid. As long as trigger signal is in level low, the camera keeps exposure and acquisition status.

Click **Acquisition Control > Trigger Activation**, and select **Rising Edge**, **Falling Edge**, **Level High** or **Level Low** as **Trigger Activation** according to actual demands.




Figure 8-18 Set Trigger Activation

# 8.5.5 Set Trigger Debouncer

The external trigger input signal of the camera may have signal bounce that may cause false trigger. Thus, it is necessary to debounce the external trigger signal, and its sequence diagram is shown below.




Figure 8-19 Trigger Debouncer Sequence Diagram

Click **Digital IO Control > Line Debouncer Time**, enter **Line Debouncer Time**, and its range is from  $1 \mu s$  to  $1000000 \mu s$ .



Figure 8-20 Set Trigger Debouncer

#### 8.6 Set Event Control

i NOTE

The event control function may differ by camera models.

The event control function allows you to enable event messages and camera events like Acquisition Start, Acquisition End, etc.

When the **Event Notification** is set to **Notification On**, the camera can generate an event and transmit a related event message to the computer whenever a specific situation occurs.

#### Steps:

- 1. Click **Event Control**, and select specific event in **Event Selector** according to actual demands.
- 2. Set Notification On as Event Notification.




Figure 8-21 Select Event

3. Right click the connected camera, and click **Event Monitor**.




Figure 8-22 Click Event Monitor

4. View the specific event information in the event monitor interface.




Figure 8-23 Event Monitor Interface

#### 8.7 Set Action Command

I NOTE

The action command function may differ by camera models.

The action command allows you to execute actions on multiple cameras at roughly the same time by using a single broadcast protocol message.

I NOTE

- The action command function is available only with client software version of V3.1.0 and higher.
- If you want to send action commands that are executed in multiple cameras at exactly the same time, it is recommended to enable Gev IEEE 1588 first by clicking Transport Layer Control > Gev IEEE 1588.

#### Steps:

- 1. Click Tool > GigE Vision Action Command.
- 2. Select **Network Interfaces** to set the subnet that the command to be sent to.
- 3. Enter the **Device Key**, **Group Key**, and **Group Mask**.




Figure 8-24 Set Action Command

[j	NOTE
wit	e specific contents entered in <b>Device Key, Group Key</b> and <b>Group Mask</b> here should be the same h those in <b>Action Device Key, Action Group Key</b> and <b>Action Group Mask</b> of the <b>Action Control</b> ture.
4.	Enable <b>Scheduled</b> .
5.	Click in <b>Benchmark Camera</b> to select one camera as benchmark camera. Once benchmark camera is selected, other cameras keep time synchronization with it.



• The delay time should NOT be shorter than the maximum time required to transmit the command across the network.

6. (Optional) Enter **Delay Time** according to actual demands.

- When the benchmark camera receives the command, all the cameras will trigger certain actions simultaneously after the specified delay time.
- 7. (Optional) Enable **Periodically Send** to enable the client to send commands periodically, and enter **Sending Interval** according to actual demands.



The default value of sending interval is 1000 ms, and its range is from 1 ms to 3600000 ms.

8. (Optional) Enable **Request Acknowledgement** to display the acknowledgement messages.

# I NOTE

Up to 50 messages can be displayed. Once the message quantity exceeds 50, the earliest message will be automatically deleted.

9. Click **Start Sending**.

# Chapter 9 I/O Output

# 9.1 Select Output Signal

The camera has 1 opto-isolated output (Line 1), and 1 bi-directional I/O (Line 2) that can be configured as output signal. Here we take **Line 2** as an example.

Click **Digital IO Control**, select **Line 2** as **Line Selector**, and select **Strobe** as **Line Mode** to set line 2 as output signal.




Figure 9-1 Set Line 2 as Output Signal

### 9.2 Set Output Signal

The output signal of the camera is switch signal that can be used to control external devices such as light source, PLC, etc.

#### 9.2.1 Enable Level Inverter

The line inverter function allows the camera to invert the electrical signal level of an I/O line, and meets requirements of different devices for high or low electrical signal level. All high signals are converted to low signals and vice versa.

Click **Digital IO Control** > **Line Selector**, select line for **Line Selector**, and enable **Line Inverter**.



Figure 9-2 Enable Line Inverter

**i** NOTE

The Line Inverter parameter is disabled by default.

### 9.2.2 Enable Strobe Signal

The strobe signal is used to directly output I/O signal to external devices when camera's event source occurs.

Click **Digital IO Control**, select different output events as **Line Source**, and enable **Strobe Enable**.

i NOTE

The specific line source may differ by camera models.




Figure 9-3 Set Line Source

For specific **Line Source**, please refer to following table for details.

Table 9-1 Line Source

No.	Name	Description
1	Exposure Start Active	It refers to output one I/O edge signal when starting exposure.
2	Acquisition Start Active	It refers to output one I/O edge signal when starting acquisition.
3	Acquisition Stop Active	It refers to output one I/O edge signal when stopping acquisition.

No.	Name	Description
4	Frame Burst Start Active	It refers to output one I/O edge signal when starting triggering and acquiring images under Burst mode.
5	Frame Burst End Active	It refers to output one I/O edge signal when stopping triggering and acquiring images under Burst mode.
6	Soft Trigger Out	It refers to output one I/O edge signal when software trigger acquisition.
7	Hard Trigger Active	It refers to output one I/O edge signal when hardware trigger acquisition.
8	Count Active	It refers to output one I/O edge signal when counter output is enabled.
9	Timer Active	It refers to output one I/O edge signal when timer output is enabled.

Regarding strobe signal, you can also set its duration, delay and pre delay.

#### Set Strobe Line Duration

After enabling strobe signal, you can set its duration. Click **Digital IO Control > Strobe Line Duration**, and enter **Strobe Line Duration**.




Figure 9-4 Set Strobe Line Duration

i NOTE

When the **Strobe Line Duration** value is 0, the strobe duration is equal to the exposure time. When the **Strobe Line Duration** value is not 0, the strobe duration is equal to **Strobe Line Duration** value.

#### Set Strobe Line Delay

The camera supports setting strobe line delay to meet actual demands. When exposure starts, the strobe output doesn't take effect immediately. Instead, the strobe output will delay according to the strobe line delay setting.

Click **Digital IO Control** > **Strobe Line Delay**, and enter **Strobe Line Delay**, and its range is from 0  $\mu$ s to 10000  $\mu$ s.




Figure 9-5 Set Strobe Line Delay

The sequence diagram of strobe line delay is shown below.




Figure 9-6 Sequence Diagram of Strobe Line Delay

#### Set Strobe Line Pre Delay

The camera also supports the function of strobe line pre delay, which means that the strobe signal takes effect early than exposure. This function is applied to the external devices that have slow response speed.

Click **Digital IO Control** > **Strobe Line Pre Delay**, and enter **Strobe Line Pre Delay**, and its range is from 0  $\mu$ s to 5000  $\mu$ s.




Figure 9-7 Set Strobe Line Pre Delay

The sequence diagram of strobe line pre delay is shown below.




Figure 9-8 Sequence Diagram of Strobe Line Pre Delay

# Chapter 10 I/O Electrical Feature and Wiring

# 10.1 I/O Electrical Feature

### 10.1.1 Line 0 Opto-isolated Input Circuit

The Line 0 opto-isolated input circuit in camera I/O control is shown below.




Figure 10-1 Line 0 Internal Circuit

# I NOTE

The maximum input current of Line 0 is 25 mA.




Figure 10-2 Input Logic Level

rable 10-1 input Electrical Feature			
Parameter Name	Parameter Symbol	Value	
Input Logic Level Low	VL	0 VDC to 1 VDC	
Input Logic Level High	VH	1.5 VDC to 24 VDC	
Input Rising Delay	TDR	1.8 μs to 4.6 μs	
Input Falling Delay	TDF	16.8 μs to 22 μs	

Table 10-1 Input Electrical Feature

# i NOTE

- Make sure the input voltage is not from 1 VDC to 1.5 VDC as the electric status between these two values are not stable.
- The breakdown voltage is 30 VDC, and keep voltage stable.

### 10.1.2 Line 1 Opto-isolated Output Circuit

The Line 1 opto-isolated output circuit in camera I/O control is shown below.




Figure 10-3 Line 1 Internal Circuit

# I NOTE

The maximum output current of Line 1 is 25 mA.




Figure 10-4 Output Logic Level

Opto-isolated output electric feature is shown in below (when the external voltage is 3.3 VDC and the external resistance is 1  $K\Omega$ ).

Table 10-2 Output Electric Feature

Parameter Name	Parameter Symbol	Value
Output Logic Level Low	VL	575 mV
Output Logic Level High	VH	3.3 V
Output Rising Time	TR	8.4 μs
Output Falling Time	TF	1.9 μs
Output Rising Delay	TDR	15 μs to 60 μs
Output Falling Delay	TDF	3 μs to 6 μs

With different external voltage and resistance, the corresponding current and the parameter of output logic level low are shown below.

Table 10-3 Parameter of Output Logic Level Low

External Voltage	External Resistance	VL	Output Current
3.3 VDC	1 ΚΩ	575 mV	2.7 mA
5 VDC	1 ΚΩ	840 mV	4.1 mA
12 VDC	2.4 ΚΩ	915 mV	4.6 mA
24 VDC	4.7 ΚΩ	975 mV	4.9 mA

# 10.1.3 Line 2 Bi-direction I/O Circuit

The Line 2 bi-direction I/O circuit in camera I/O control is shown below. The Line 2 can be configured as input signal or as output signal.




Figure 10-5 Line 2 Internal Circuit

#### **Line 2 Configured as Input**

With the condition of 100  $\Omega$  and 5 VDC, the logic level and electrical feature of configuring Line 2 as output are shown below.




Figure 10-6 Input Logic Level

Table 10-4 Electrical Feature of Line 2 Input

Parameter Name	Parameter Symbol	Value
Input Logic Level Low	VL	0 VDC to 0.5 VDC
Input Logic Level High	VH	1.5 VDC to 24 VDC
Input Rising Time	TDR	< 1 μs
Input Falling Time	TDF	< 1 µs

# i NOTE

 Make sure the input voltage is not from 0.5 VDC to 1.5 VDC as the electric status between these two values are not stable.

- The breakdown voltage is 30 VDC, and keep voltage stable.
- To prevent damage to the GPIO pin, please connect GND first and then input voltage in Line 2.

#### **Line 2 Configured as Output**

When the environment temperature is 25 °C (77 °F), the relation among external voltage, resistance and the output level low is shown below.

Table 10-5 Parameter of Output Logi	c Leve	l Low
-------------------------------------	--------	-------

External Voltage	External Resistance	VL (GPIO2)
3.3 V	1 ΚΩ	160 mV
5 V	1 ΚΩ	220 mV
12 V	1 ΚΩ	460 mV
24 V	1 ΚΩ	860 mV
30 V	1 ΚΩ	970 mV

# i NOTE

The maximum current is 25 mA and the output impedance is 40  $\Omega$ .

When the voltage of external resistance (1  $K\Omega$ ) is pulled up to 5 VDC, the logic level and electrical feature of configuring Line 2 as output are shown below.




Figure 10-7 Output Logic Level

Table 10-6 Electrical Feature of Line 2 Output

Parameter Name	Parameter Symbol	Value
Output Logic Level Low	VL	220 mV
Output Logic Level High	VH	4.75 VDC
Output Rising Time	TR	0.06 μs
Output Falling Time	TF	0.016 μs
Output Rising Delay	TDR	0 μs to 4 μs
Output Falling Delay	TDF	< 1 μs

# 10.2 I/O Wiring

The camera has different appearance with varied models. Here we take type I camera as an example to introduce I/O wiring.

# **i** NOTE

For specific camera appearance, cable color and I/O wiring, please refer to the actual one you got.

# 10.2.1 Line 0 Wiring

When the camera uses Line 0 as hardware trigger source, wirings are different with different external devices of input signal.

#### PNP Device




Figure 10-8 Line 0 Connecting to PNP Device

#### NPN Device

If the VCC of NPN device is 24 VDC, and it is recommended to use 1 K $\Omega$  to 4.7 K $\Omega$  pull-up resistor. If the VCC of NPN device is 12 VDC, and it is recommended to use 1 K $\Omega$  pull-up resistor.

PWR VÇC Camera Power **Device Power** Supply Supply 0 Signal Line NPN Device Opt-Iso in Device Power I/O Ground Ground Camera Power Ground GND of VCC GND of PWR

Figure 10-9 Line 0 Connecting to NPN Device

#### Switch

If the VCC of switch is 24 VDC, and it is recommended to use 1 K $\Omega$  to 4.7 K $\Omega$  resistor to protect circuit.




Figure 10-10 Line 0 Connecting to a Switch

### 10.2.2 Line 1 Wiring

When the camera uses Line 1 as output signal, wirings are different with different external devices.

#### PNP Device




Figure 10-11 Line 1 Connecting to PNP Device

#### NPN Device

If the VCC of NPN device is 24 VDC, and it is recommended to use 1 K $\Omega$  to 4.7 K $\Omega$  pull-up resistor. If the VCC of NPN device is 12 VDC, and it is recommended to use 1 K $\Omega$  pull-up resistor.




Figure 10-12 Line 1 Connecting to NPN Device

# 10.2.3 Line 2 Wiring

As bi-direction I/O Circuit, Line 2 can be used as both input signal and output signal.

#### Line 2 Configured as Input

When the camera uses Line 2 as hardware trigger source, wirings are different with different external devices of input signal.

#### PNP Device

It is recommended to use 330  $\Omega$  pull-down resistor.




Figure 10-13 Line 2 Connecting to PNP Device as Input

#### NPN Device

If the VCC of NPN device is 24 VDC, and it is recommended to use 1 K $\Omega$  to 4.7 K $\Omega$  pull-up resistor. If the VCC of NPN device is 12 VDC, and it is recommended to use 1 K $\Omega$  pull-up resistor.




Figure 10-14 Line 2 Connecting to NPN Device as Input

#### Switch

If the VCC of switch is 24 VDC, and it is recommended to use 1 K $\Omega$  to 4.7 K $\Omega$  resistor to protect circuit.




Figure 10-15 Line 2 Connecting to a Switch as Input

#### **Line 2 Configured as Output**

When the camera uses Line 2 as output signal, wirings are different with different external devices.

#### PNP Device




Figure 10-16 Line 2 Connecting to PNP Device as Output

#### NPN Device

If the VCC of NPN device is 24 VDC, and it is recommended to use 1 K $\Omega$  to 4.7 K $\Omega$  pull-up resistor. If the VCC of NPN device is 12 VDC, and it is recommended to use 1 K $\Omega$  pull-up resistor.




Figure 10-17 Line 2 Connecting to NPN Device as Output

# Chapter 11 Image Parameter

#### 11.1 View Resolution

Click Image Format Control, and view Width Max and Height Max. Width Max stands for the max. pixels per inch in width direction and Height Max stands for the max. pixels per inch in height direction.



Figure 11-1 View Resolution



The camera displays the image with max. resolution by default.

#### **11.2 Set ROI**

If you are only interested in a certain region of the image, you can set a Region of Interest (ROI) for the camera. Setting Region of Interest can reduce the bandwidth of the image being transmitted. Thus increasing the frame rate to some extent.

# i NOTE

- The camera currently supports 1 ROI only, that is, there is Region 0 for Region Selector parameter only.
- Region of interest can be set only when you stop real-time acquisition.

Click Image Format Control > Region Selector, and enter Width, Height, Offset X, and Offset Y.

- Width: it stands for horizontal resolution in ROI area.
- Height: it stands for vertical resolution in ROI area.
- Offset X: it refers to the horizontal coordinate of the upper left corner of the ROI.
- Offset Y: it refers to the vertical coordinate of the upper left corner of the ROI.




Figure 11-2 Set ROI



- The Width value plus Offset X value should not be larger than Width Max parameter value, Height value plus Offset Y value should not be larger than Height Max parameter value
- The ROI function may differ by camera models.

# 11.3 Set Image Reverse

# i NOTE

The image reverse function may differ by camera models.

**Reverse X** refers to the image reverses in a horizontal way, and **Reverse Y** refers to the image reverses in a vertical way.

You can click **Image Format Control**, and enable **Reverse X** or **Reverse Y** according to actual demands.




Figure 11-3 Set Image Reverse




Figure 11-4 Image Reverse Comparison

# 11.4 Set Pixel Format

I NOTE

The pixel format may differ by camera models.

Table 11-1 Pixel Size of Different Pixel Formats

Pixel Format	Pixel Size (Bits/Pixel)
Mono 8, Bayer 8	8
Mono 10 Packed, Mono 12 Packed, Bayer 10	12

Pixel Format	Pixel Size (Bits/Pixel)
Packed, Bayer 12 Packed	
Mono 10/12, Bayer 10/12, YUV422Packed, YUV 422 (YUYV) Packed	16
RGB 8, BGR 8	24

Click Image Format Control > Pixel Format, and set Pixel Format according to actual demands.




Figure 11-5 Set Pixel Format

#### 11.5 Set Test Pattern

# **i** NOTE

The test pattern may differ by camera models.

The camera supports test pattern function. When there is exception in real-time image, you can check whether image of test mode have similar problem to determine the reason. This function is disabled by default, and at this point, the outputted image by the camera is real-time image. If this function is enabled, the outputted image by the camera is test image.

Click Image Format Control > Test Pattern, and set Test Pattern according to actual demands




Figure 11-6 Set Test Pattern

The mono camera offers 5 test patterns, including **Mono Bar**, **Checkboard**, **Oblique Mono Bar**, **Gradual Mono Bar**, and **Test Image 1**.

The color camera offers 7 test patterns, including Mono Bar, Checkboard, Oblique Mono Bar, Gradual Mono Bar, Vertical Color Bar, Horizontal Color Bar, and Test Image 1.




Figure 11-7 Mono Bar




Figure 11-8 Checkboard




Figure 11-9 Oblique Mono Bar




Figure 11-10 Gradual Mono Bar




Figure 11-11 Vertical Color Bar



Figure 11-12 Horizontal Color Bar




Figure 11-13 Test Image 1



The pattern of the test image 1 may differ by camera models.

# 11.6 Set Binning

The purpose of setting binning is to enhance sensibility. With binning, multiple sensor pixels are combined as a single pixel to reduce resolution and improve image brightness.

Click **Image Format Control**, and set **Binning Horizontal** and **Binning Vertical** according to actual demands.



Figure 11-14 Set Binning

# i NOTE

- **Binning Horizontal** refers to the image's width, and **Binning Vertical** refers to the image's height.
- The binning function may differ by camera models.

### 11.7 Set Decimation

The decimation feature allows you to reduce the number of sensor pixel columns or rows that are transmitted by the camera. This procedure is also known as "subsampling". It reduces the amount of data to be transferred and may increase the camera's frame rate.

Click **Image Format Control**, and set **Decimation Horizontal** and **Decimation Vertical** according to actual demands.



Figure 11-15 Set Decimation

# i NOTE

- Decimation Horizontal refers to the image's width, and Decimation Vertical refers to the image's height.
- The decimation function may differ by camera models.

### 11.8 Set Exposure Time Mode

**□i** NOTE

The exposure time mode may differ by camera models.

The camera offers 2 types of exposure time modes, including **Ultrashort** mode and **Standard** mode. Click **Acquisition Control** > **Exposure Time Mode**, and set **Exposure Time Mode** according to actual demands.




Figure 11-16 Set Exposure Time Mode

i NOTE

If the camera you got does not support **Ultrashort** exposure time mode, and then there is no **Exposure Time Mode** parameter, and your camera supports **Standard** exposure time mode only by default.

### 11.9 Set Exposure Auto

Under the ultrashort exposure time mode, the camera exposes within an ultrashort time. The camera supports **Off** exposure mode only, you can adjust **Exposure Time** manually only.

Under the standard exposure time mode, the camera supports 3 types of exposure methods: **Off**, **Once** and **Continuous**. Click **Acquisition Control** > **Exposure Auto**, and select **Exposure Auto** according to actual demands. The exposure method and principle are shown below.

Table 11-2 Exposure Method and Principle

Exposure Method	Principle
Off	The camera exposures according to the value configured by user in <b>Exposure Time</b> .
Once	Adjust the exposure time automatically according to the image brightness. After adjusting, it will switch to <b>Off</b> Mode.
Continuous	Adjust the exposure time continuously according to the image brightness.

When the **Exposure Auto** is set as **Off**, you can enter **Exposure Time** manually. When the **Exposure Auto** is set as **Once** or **Continuous**, the exposure time should be within the range of **Auto Exposure Time Lower Limit** and **Auto Exposure Time Upper Limit**.




Figure 11-17 Set Exposure Time under Once or Continuous Mode

# i NOTE

If the camera is under **Continuous** exposure method, once external trigger mode is enabled, the camera will automatically switch to **Off** exposure mode.

#### 11.10 Set HDR

### i NOTE

The HDR function may differ by camera models.

The camera supports HDR (High Dynamic Range) function that the camera acquires images based on 4 sets of settings, and each with its own exposure time and gain.

Click **Acquisition Control**, enable **HDR Enable**, select **0**, **1**, **2** or **3** as **HDR Selector**, and set corresponding **HDR Shutter** and **HDR Gain**.



Figure 11-18 Set HDR




Figure 11-19 HDR Polling

#### 11.11 Set Gain



The gain function may differ by camera models.

The camera has 2 types of gain, including the analog gain and digital gain. The analog gain is applied before the signal from the camera sensor is converted into digital values, while digital gain is applied after the conversion.

### 11.11.1 Set Analog Gain

The camera supports 3 types of analog gain modes: **Off, Once** and **Continuous**. Click **Analog Control,** and select **Gain Auto** according to actual demands. The analog gain mode and principle are shown below.

Table 11-3 Analog Gain Mode and Principle

Gain Mode	Principle
Off	The camera adjusts gain according to the value configured by user in <b>Gain</b> .
Once	Adjust the gain automatically according to the image brightness. After adjusting, it will switch to <b>Off</b> Mode.
Continuous	Adjust the gain continuously according to the image brightness.

When the analog gain is set as **Once** or **Continuous**, the gain should be within the range of **Auto Gain Lower Limit** and **Auto Gain Upper Limit**.



Figure 11-20 Set Gain under Once or Continuous Mode

### I NOTE

When increasing the analog gain, the image noise will increase too, which will influence image quality. If you want to increase image grayscale value, it is recommended to increase the camera's exposure time. If the exposure time reaches its upper limit, and at this point, you can increase analog gain.

# 11.11.2 Set Digital Gain

Apart from analog gain, the camera supports digital gain function. When analog gain reaching its upper limit and the image is still too dark, it is recommended to improve image brightness via digital gain.

Click **Analog Control**, enable **Digital Shift Enable**, and enter **Digital Shift** according to actual demands. The range of **Digital Shift** is from -6 to 6.




Figure 11-21 Set Digital Gain

# 11.12 Set Brightness

The camera brightness refers to the brightness when the camera adjusts image under **Once** or **Continuous** exposure mode, or **Once** or **Continuous** gain mode. You can set brightness as shown below.

### i NOTE

You should enable **Once** or **Continuous** exposure mode, or **Once** or **Continuous** gain mode first before setting brightness.

Click **Analog Control** > **Brightness**, and set **Brightness** according to actual demand, and its range is from 0 to 255.




Figure 11-22 Set Brightness

### **i** NOTE

After setting brightness, the camera will automatically adjust exposure time to let image brightness reach target one. Under **Once** or **Continuous** exposure mode, or **Once** or **Continuous** gain, the higher the brightness value, the brighter the image will be.

### 11.13 Set Black Level

The camera supports black level function that allows you to change the overall brightness of an image by changing the gray values of the pixels by a specified amount.

Click **Analog Control** > **Black Level Enable**, enable **Black Level Enable**, and enter **Black Level** according to actual demands. The range of black level is from 0 to 4095.



Figure 11-23 Set Black Level

### 11.14 Set White Balance



White balance is only available for color cameras.

The white balance refers to the camera color adjustment depending on different light sources. Adjust the Gain Value of the image's R channel and B channel to keep white regions white under different color temperatures. Ideally, the proportion of R channel, G channel and B channel in the white region is 1:1:1.

Click **Analog Control** > **Balance White Auto**, and select **Balance White Auto** according to actual demands.

White Balance Mode	Description
Off	You need to set the R, G, B value manually, between 1 and 4095. 1024 means ratio is 1.0
Once	Automatic white balance once. Adjust the white balance for a certain amount of time then stop. It implements an algorithm that finds possible gray areas in the Bayer data.
Continuous	Continuous automatic white balance. It implements an algorithm that finds possible gray areas in the Bayer data.

Table 11-4 White Balance Status Description

It is recommended to correct white balance when there is great difference between the camera's color effect and actual effect. You can correct white balance as shown below.

#### Steps:

1. Put a white paper in the range of the camera's field of view, and make sure the paper covers the entire field of view.

- 2. Set exposure and gain. It is recommended to set image brightness value between 120 and 160.
- 3. Select **Once** as **Balance White Auto**, and the camera will automatically adjust white balance for once.

If there is still great difference between correction effect and actual color, it is recommended to correct white balance according to following steps.

### Steps:

- 1. Select **Off** as **Balance White Auto**. At this time, **Balance Ratio** is **1024**.
- 2. Find corresponding R/G/B channel in **Balance Ratio Selector**. Here we take **Green** as an example.
- 3. Find camera's R/G/B value.
- 4. Take **Green** as correction standard, and manually adjust other two channels (R channel and B channel) to let these three channels have same value.

## NOTE

- Here we take Green as an example. For specific Balance Ratio Selector value, please refer to the actual condition.
- In order to avoid repeated correction after rebooting the camera, it is recommended to save white balance parameter to **User Set** after white balance correction. You can refer to the Section **Save and Load User Set** for details.
- If the light source and color temperature in environment change, you need to correct white balance again.

### 11.15 Set Gamma Correction

The camera supports Gamma correction function. Generally, the output of the camera's sensor is linear with the photons that are illuminated on the photosensitive surface of the sensor. Gamma correction provides a non-linear mapping mechanism as shown below.

- Gamma value between 0.5 and 1: image brightness increases, dark area becomes brighter.
- Gamma value between 1 and 4: image brightness decreases, dark area becomes darker.




Figure 11-24 Gamma Curve

There are 2 types of Gamma correction, including **User** mode and **sRGB** mode. You can set User mode as shown below.

### Steps:

- 1. Click Analog Control > Gamma Selector.
- 2. Select User as Gamma Selector.
- 3. Enable Gamma Enable.
- 4. Enter **Gamma** according to actual demands, and its range is from 0 to 4.



Figure 11-25 Set User Mode

You can set sRGB mode as shown below.

### Steps:

- 1. Click Analog Control > Gamma Selector.
- 2. Select sRGB as Gamma Selector.
- 3. Enable **Gamma Enable**.




Figure 11-26 Set sRGB Mode

## 11.16 Set Sharpness

i NOTE

The sharpness function is available when the camera is in Mono and YUV pixel format.

The camera supports sharpness function that can adjust the sharpness level of the image edge, and this function is disabled by default.

Click **Analog Control** > **Sharpness Enable**, enable **Sharpness Enable**, and enter **Sharpness** according to actual demands. The range of the brightness is from 0 to 100.



Figure 11-27 Set Sharpness

### 11.17 Set Channel Correct Mode

I NOTE

The channel correction function may differ by camera models.

The channel correction function allows you to adjust the image's uniformity, and you can set channel correct mode as shown below.

Click **Analog Control** > **Channel Correct Mode**, and select **Channel Correct Mode** according to actual demands.



Figure 11-28 Set Channel Correct Mode

### 11.18 Set AOI

I NOTE

The AOI function may differ by camera models.

The camera supports AOI function that can adjust the brightness and white balance of the entire image based on the area you selected.

### Steps:

- Click Analog Control > Auto Function AOI Selector, and select AOI 1 or AOI 2 Auto Function AOI Selector.
- 2. Enter Auto Function AOI Width, Auto Function AOI Height, Auto Function AOI Offset X, and Auto Function AOI Offset Y according to actual demands.
- Enable Auto Function AOI Usage Intensity if AOI 1 is selected as Auto Function AOI Selector. Or enable Auto Function AOI Usage White Balance if AOI 2 is selected as Auto Function AOI Selector.




Figure 11-29 Set AOI

## 11.19 Set Color Transformation Control

i NOTE

The function of color transformation control is only available for color cameras.

The color transformation control is used to restore color and eliminate the overlap in the color channels.

Click **Color Transformation Control**, select **Color Transformation Value Selector** according to actual demands, and enable **Color Transformation Enable**.



Figure 11-30 Set Color Transformation Control



Currently, **RGB** to **RGB** is available for **Color Transformation Selector** only.

### 11.20 Set Hue and Saturation

## I NOTE

Hue and saturation are only available for color cameras.

### Hue

Adjusting the hue shifts the colors of the image.

Click **Analog Control**, enable **Hue Enable**, enter **Hue** according to actual demands, and its range is from 0 to 255.



Figure 11-31 Set Hue

#### Saturation

Adjusting the saturation changes the colorfulness of the colors. A higher saturation, for example, makes colors easier to distinguish.

Click **Analog Control**, enable **Saturation Enable**, enter **Saturation** according to actual demands, and its range is from 0 to 255.



Figure 11-32 Set Saturation

### 11.21 Set LUT

A Look-Up Table (LUT) is a customized grayscale-mapping table. The LUT allows you to replace the pixel values in your images by values defined by you.

### Steps:

- 1. Click **LUT Control**, and enable **LUT Enable**.
- 2. Enter LUT Index according to actual demands, and its range is from 0 to 1023.
- 3. Enter **LUT Value** according to actual demands, and its range is from 0 to 4095.




Figure 11-33 Set LUT



You cannot use Gamma correction function and LUT function at the same time.

## 11.22 Set Shading Correction

I NOTE

The shading correction function may differ by camera models.

The camera supports shading correction function that improves the image uniformity when you acquire a non-uniformity image due to external conditions. The shading correction type includes NUC correction, FPNC correction, PRNUC correction, and LSC correction.

### NUC, FPNC and PRNUC Correction

Click **Shading Correction**, and enable **NUC Enable**. The **FPNC Enable** and **PRNUC Enable** will be automatically enabled or disabled according to the camera's condition.



Figure 11-34 NUC Enable

### LSC Correction



The steps for LSC correction may differ by camera models.

LSC correction stands for Lens Shading Correction that eliminates non-uniform illumination brought by lens.

### Steps:

- 1. Click Shading Correction, select LSC Correction as Shading Selector.
- 2. Click Execute in Activate Shading.
- 3. Enable LSC Enable.




Figure 11-35 LSC Correction

# **Chapter 12 Other Functions**

## 12.1 Device Control

I NOTE

The specific device control parameters may differ by camera models.

In the **Device Control** attribute, you can view device information, edit device name, reset device, etc. The specific parameters in **Device Control** attribute are shown below.

Table 12-1 Device Control Parameter Description

Parameter	Read/Write	Description
Device Type	Read only	It is the device type.
Device Scan Type	Read only	It is the scan type of the sensor.
Device Vendor Name	Read only	It is the name of device manufacturer.
Device Model Name	Read only	It is the device model.
Device Manufacture Info	Read only	It is the manufacturer information.
Device Version	Read only	It is the device version.
Device Firmware Version	Read only	It is the device firmware version.
Device Serial Number	Read only	It is the device serial number.
Device ID	Read only	It is the device ID.
Device User ID	Read and write	Device name and it is empty by default. You can set according to your preference.
		<ul> <li>If User ID is empty, the client software displays the device model.</li> </ul>
		If you set it, the client software displays the     User ID you set.
Device Uptime(s)	Read only	It is the period of time when device is powered up.

Parameter	Read/Write	Description	
Board Device Type	Read only	It is the device type.	
Device Connection Selector	Read and write	It is the ID of GenICam XML.	
Device Connection Speed (Mbps)	Read only	It is the device connection speed.	
Device Link Selector	Read and write	It selects device link.	
Device Link Speed(Mbps)	Read only	It is the link speed.	
Device Link Connection Count	Read only	It is the link connection quantity.	
Device Link Heartbeat Mode	Read and write	It enables heartbeat mode or not.	
Device Stream Channel Count	Read only	It counts data packet quantity.	
Device Stream Channel Selector	Read and write	It is the character set used in register.	
Device Stream Channel Type	Read only	It is the stream channel type.	
Device Stream Channel Link	Read only	It is the stream channel link quantity.	
Device Stream Channel Endianness	Read only	It is the image data endianness.	
Device Stream Channel Packet Size(B)	Read and write	It is the data packet size.	
Device Event Channel Count	Read only	It is the channel quantity that the device supports.	
Device Character Set	Read only	It is the character set used in register.	

Parameter	Read/Write	Description	
Device Reset	Read and write	Click <b>Execute</b> to reset the device.	
Device Temperature Selector	Read and write	It selects device component temperature.	
Device Temperature	Read only	It displays the real-time temperature of the device component you selected in <b>Device Temperature Selector</b> .	
Find Me	Read and write	Click <b>Execute</b> to let red indicator flash once, and find device.	
Device Max Throughput(Kbps)	Read only	It is the maximum flow of device operation.	

## 12.2 Embedded Information in Image

## I NOTE

The embedded information function and chunk data function may differ by camera models.

The camera supports adding and embedding the collection information to the image data. You can set in the client software and define which information to be embedded in the image data.

Embedded information includes following categories: **Timestamp**, **Gain**, **Exposure**, **Brightness Info**, **Frame Counter**, **Ext Triggering Count**, **Line Input Output**, and **ROI Position**.

Each category of embedded information has its unique data format.

Table 12-2 Embedded Information Data Format

No.	Information Type	Byte	Data Format Description	
1	Timestamp	4 Bytes	4 bytes are used to transfer the timestamp information.	
2	Gain	4 Bytes	Bytes 4 bytes are used to transfer the gain information.  Each low 8 bits of the 4 valid data are combined to transfer the gain information.	
			Value Range: 0 to 1023.  Note: High bits will be complemented with 0 automatically.	

No.	Information Type	Byte	Data Format Description
3	Exposure	4 Bytes	4 bytes are combined to show the exposure time, and the unit is $\mu s$ .
4	Brightness Info	4 Bytes	4 bytes are used to transfer the brightness information.  Value Range: 0 to 4095.  Note: High bits will be complemented with 0 automatically.
5	Frame Counter	4 Bytes	Value Range: 0 to 2 <sup>32</sup> -1.
6	Ext Trigger Count	4 Bytes	Value Range: 0 to 2 <sup>32</sup> -1.
7	Line Input Output	4 Bytes	4 bytes are used to transfer the line input and output information.
8	ROI Position	8 Bytes	4 bytes stand for the start point, and 4 bytes stand for the length and width.  In specific, the column coordinate occupies 2 bytes, and the row coordinate occupies 2 bytes. The column coordinate information comes first.  In specific, the length and width occupy 2 bytes respectively, and the length information comes first.

## i NOTE

- The specific embedded information categories may differ by camera models.
- The camera embeds category that you select into the image data. The ROI area do not influence collection information embedding. If the ROI area is small and there is not enough space in first line image, and then the collection information will be embedded into the second line image.
- The low 8-bit of each valid data storages image embedded information.

Click **Image Format Control > Embedded Image Info Selector**, select specific parameters as **Embedded Image Info Selector**, and enable **Frame Spec Info**.

You can click in the control toolbar to view the embedded information.




Figure 12-1 Set Embedded Information

You can also use the chunk data function to add the embedded information in images. The chunk data function allows you to generate supplementary image data and append that data to every image that you acquire.

I NOTE

The chunk data function may differ by camera models.

### Steps:

- 1. Click Chunk Data Control.
- 2. Enable Chunk Mode Active.
- 3. Select specific parameters in **Chunk Selector** according to actual demands.
- 4. Enable Chunk Enable.



Figure 12-2 Set Chunk Data Control

### 12.3 Set Multicast

I NOTE

The multicast function may differ by camera models.

The multicast function allows you to access the same camera via multiple PCs, and it has 3 modes as follows.

**Controller and Data Receiver**: This mode allows you to read and edit the camera's parameters, and get its image data.

**Controller**: This mode allows you to read and edit the camera's parameters, but you cannot get its image data.

**Data Receiver**: This mode allows you read the camera's parameters and get its image data, but you cannot edit the camera's parameters.

## i NOTE

- The same camera can be connected to only one MVS client software via the controller and data receiver or the controller mode at the same time, while in the data receiver mode, the same camera can be connected to multiple client software.
- When the multicast function is enabled, the camera icon on the client software of other PCs will become , and you can connect the camera via the data receiver mode.
- When you connect the camera via the data receiver mode, the camera icon on the client software of your PC will become , and at this time, you can read its parameters only.
- You can set multicast function for both the available camera and connected camera, but the specific settings are different.

For the available camera, you can set multicast function as follows.

### Steps:

1. Right click the available camera, and click **Multicast Settings**.




Figure 12-3 Click Multicast Settings

- 2. Select Role, and enter the IP Address and Port.
- 3. Click OK.




Figure 12-4 Set Multicast for Available Camera

For the connected camera, you can set multicast function as follows.

## i NOTE

For the connected camera, only the **Controller and Data Receiver** is available.

### Steps:

1. Right click the connected camera, and click **Multicast Settings**.




Figure 12-5 Click Multicast Settings

- 2. Enable the multicast function, and edit the IP Address and Port.
- 3. Click OK.




Figure 12-6 Set Multicast for Connected Camera

### 12.4 File Access Control



The file access control function may differ by camera models.

The file access control allows you to export or import the camera's feature configuration (including User Set 1, User Set 2, or User Set 3) or DPC (Defective Pixel Correction) data to or from the local PC as the mfa format.

### Steps:

- 1. Select a camera in the device list.
- 2. Click to open the **File Access** interface.




Figure 12-7 File Access

3. Select a User Set (User Set 1, User Set 2, or User Set 3) or DPC from the drop-down list.




Figure 12-8 File Access Interface

4. Click **Import** or **Export** to import or export the camera's feature configuration or DPC data according to actual demands.

i NOTE

Importing and exporting the camera's feature configuration or DPC data among the same model cameras are supported.

## 12.5 Transport Layer Control

I NOTE

The specific transport layer control parameters may differ by camera models.

You can go to **Transport Layer Control** to view the camera's load size, GEV version, etc.

Table 12-3 Transport Layer Control Description

Parameter	Read/Write	Description
Paylode Size (B)	Read only	It is the camera's load size.
GEV Version Major	Read only	It is the major version in GEV version.
GEV Version Minor	Read only	It is the minor version in GEV version.
GEV Device Mode Is Big Endian	Read only	It is the endianness in device's register.
GEV Device Mode Character Set	Read only	It is the character set in device's register.
GEV Interface Selector	Read only	It sets which physical network interface to be controlled.
GEV MAC Address	Read only	It is the MAC address of the network interface.
GEV Supported Option Selector	Read and write	It selects the GEV option to interrogate for existing support.
GEV Supported Option	Read only	It indicates whether the selected GEV option is supported or not.
GEV Current IP Configuration	Read only	It indicates whether the Link Local Address IP configuration scheme is activated on the given

Parameter Read/Write		Description	
		network interface.	
GEV Current IP Configuration Read and write		It indicates whether the DHCP IP configuration scheme is activated on the given network interface.	
GEV Current IP Configuration Persistent IP	Read and write	It indicates whether persistent IP configuration scheme is activated on the given network interface.	
DEV PAUSE Frame Reception	Read and write	It controls whether incoming pause frames are handled on the given logical link.	
GEV Current IP Address	Read only	It is the current IP address for the given network interface.	
GEV Current Subnet Mask	Read only	It is the current subnet mask of the given interface.	
GEV Current Default Gateway	Read only	It is the default gateway IP address to be used on the given network interface.	
GEV First URL Read only		It is the first choice of URL for the XML device description file.	
GEV Second URL	Read only	It is the second choice of URL to the XML device description file.	
GEV Number Of Interfaces	Read only	It indicates the number of physical network interfaces supported by this device.	
GEV Persistent IP Address	Read and write	It indicates the persistent IP address for this network interface. It is only used when the device boots with the persistent IP configuration scheme.	
GEV Persistent Subnet Mask	Read and write	It indicates the persistent subnet mask associated with the persistent IP address on this network interface. It is only used when the device boots with the persistent IP configuration scheme.	
GEV Persistent Default Gateway	Read and write	It indicates the persistent default gateway for this network interface. It is only used when the device boots with the persistent IP configuration scheme.	

Parameter	Read/Write	Description	
GEV Link Speed	Read only	It indicates the speed of transmission negotiated by the given network interface in Mbps.	
GEV Message Channel Count Read only		It indicates the number of message channels supported by this device.	
GEV Stream Channel Count	Read only	It indicates the number of stream channels supported by this device.	
GEV Heartbeat Timeout(ms)	Read and write	It indicates the current heartbeat timeout in milliseconds.	
GEV Heartbeat Disable	Read and write	It disables the GEV Heartbeat.	
GEV Timestamp Tick Frequency(Hz)	Read only	It indicates the number of timestamp ticks in 1 second (frequency in Hz).	
Timestamp Control Latch	Read and write	It latches the current timestamp value of the device.	
Timestamp Control Reset	Read and write	It resets the timestamp value for the device.	
Timestamp Control Latch Reset	Read and write	It resets the timestamp control latch.	
Timestamp Value	Read only	It is a read only element. It indicates the latched value of the timestamp.	
GEV CCP	Read and write	It controls the device access privilege of an application.	
GEV MCP Host Port	Read and write	It controls the port to which the device must send messages. Setting this value to 0 closes the message channel.	
GEV MCDA	Read and write	It controls the destination IP address for the message channel.	

Parameter	Read/Write	Description
GEV MCTT (ms)	Read and write	It provides the transmission timeout value in milliseconds.
GEV MCRC	Read and write	It controls the number of retransmissions allowed when a message channel message times out.
GEV MCSP	Read only	It indicates the source port for the message channel.
GEV Stream Channel Selector	Read only	It selects the stream channel to control.
GEV SCP Interface Index	Read only	It is the Index of network interface to be used.
GEV SCP Host Port	Read and write	It is the host port of the channel
GEV SCP Direction	Read only	It transmits or receives the channel.
GEV SCPS Fire Test Packet	Read only	It sends a test packet.
GEV SCPS Do Not Fragment	Read and write	The state of this feature is copied into the "do not fragment" bit of the IP header of each stream packet.
GEV SCPS Big Endian	Read only	It is the Endianness of multi-byte pixel data for this stream.
GEV SCPS Packet Size(B)	Read and write	It specifies the stream packet size (in bytes) to send on this channel.
GEV SCPD	Read and write	It indicates the delay (in timestamp counter units) to insert between each packet for this stream channel.
GEV SCDA	Read and write	It indicates the destination IP address for this stream channel.
GEV SCSP	Read only	It indicates the source UDP port address for this stream channel.

Parameter	Read/Write	Description
Gev IEEE 1588	Read and write	It enables the IEEE 1588 Precision Time Protocol to control the timestamp register.
Gev GVSP Extended ID Mode	Read and write	It enables the extended ID mode.

### 12.6 Set Fan



The fan function may differ by camera models.

For cameras with fan, you can go to **Analog Control** > **Fan Open Threshold** to set fan parameters.



Figure 12-9 Set Fan

When the camera's temperature is higher than the value you set in **Fan Open Threshold**, the fan starts to work. Otherwise, the fan stops working.

i NOTE

The temperature unit here is Celsius degree.

### 12.7 Save and Load User Set

The camera supports 4 sets of parameters, including 1 default set and 3 user sets. The relation among 4 sets of parameters is shown below.




Figure 12-10 Parameter Relation

You can save parameters, load parameters and set user default as shown below.

#### Save Parameters

### Steps:

- 1. Click **User Set Control**, and select a user set in **User Set Selector**. Here we take selecting **User Set 1** as an example.
- 2. Click **Execute** in **User Set Save** to save parameters.




Figure 12-11 Save User Set

### Load Parameters

### Steps:

- 1. Click **User Set Control**, and select a user set in **User Set Selector**. Here we take selecting **User Set 1** as an example.
- 2. Click **Execute** in **User Set Load** to load parameters to the camera, as shown below.




Figure 12-12 Load User Set

i NOTE

Loading parameters is available when connecting with camera, but without acquisition.

### Set User Default

You can also set default parameter by selecting parameter from drop-down list of **User Set Default**, as shown below.




Figure 12-13 Set User Default

### 12.8 Update Firmware

The camera supports firmware updating via the MVS client software.

## I NOTE

- Before updating, make sure power cable and others are properly connected.
- Please use the firmware package of the corresponding camera model for updating.

### Steps:

- 1. Click **Tool > Firmware Updater** to open the update interface.
- 2. Select corresponding device type like GigE, USB, or Camera Link.
- 3. Click loselect the camera you want to update.
- 4. Click to select the update file in the local computer.
- 5. Click **Update** to start updating.




Figure 12-14 Update Firmware

## **i** NOTE

- The camera will reboot automatically after updating the firmware.
- The firmware updating process may take a few minutes, please wait patiently.
- During firmware updating, do not disconnect the camera or switch power off.

# **Chapter 13 Trouble Shooting**

Table 13-1 Trouble Shooting

No.	Trouble	Possible Reason	Solution
1	No camera found when running the MVS client software.	Camera is not started up normally, or network cable connection error.	Check camera power wiring (observe the indicator), and check network connection.
2	Camera connection error.	Camera and client software are not in the same network segment.	Use MVS IP Configurator tool to find the camera and edit its IP address.
3	Live view is black.	Aperture is closed, or the camera exception occurs.	Open the aperture or reboot the camera.
4	Live view is normal, but the camera cannot be triggered.	Incorrect wiring or the trigger mode is not enabled.	1. Check whether the camera trigger mode and related trigger signal input are normal in the current environment.
			2. Check whether the wiring is correct under corresponding triggering mode.
5	The gigabit Ethernet becomes the fast Ethernet.	The network cable is damaged.	Check whether the network cable is damaged.

# **Chapter 14 Revision History**

Table 14-1 Revision History

No.	Version No.	Document No.	Date	Revision Details
1	1.0.0	UD12911B	Jan. 9, 2019	Original version.
2	1.0.1	UD15735B	Jul. 24, 2019	<ul> <li>Add Section Set Anyway Trigger.</li> <li>Modify Section Set Action Command.</li> <li>Add Section Set Color Transformation Control.</li> <li>Add Section Set Output Signal.</li> <li>Adjust user manual structure.</li> </ul>
3	3.4.9	UD19137B	April 8, 2020	<ul> <li>Add Section Overview.</li> <li>Modify Section Appearance.</li> <li>Modify Section Client Software Layout.</li> <li>Add Section Sensor Shutter Mode.</li> <li>Modify Section Set Pixel Format.</li> <li>Modify Section Set Test Pattern.</li> <li>Add Section Set Shading Correction.</li> <li>Modify Section Transport Layer Control.</li> <li>Add Section Set Fan</li> </ul>

# Appendix A Camera Parameter Index

Table Appendix A-1 Camera Parameter Index

Attribute	Parameter	Section
Device Control	Device Type	Section Device Control
	Device Scan Type	
	Device Vendor Name	
	Device Model Name	
	Device Manufacturer Info	
	Device Version	
	Device Firmware Version	
	Device Serial Number	
	Device ID	
	Device User ID	
	Device Uptime(s)	
	Board Device Type	
	Device Connection Selector	
	Device Connection Speed (Mbps)	
	Device Link Selector	
	Device Link Speed (Mbps)	
	Device Link Connection Count	
	Device Link Heartbeat Mode	
	Device Stream Channel Count	
	Device Stream Channel Selector	
	Device Stream Channel Type	

	Device Stream Channel Link		
	Device Stream Channel Endianness		
	Device Stream Channel Packet Size (B)		
	Device Event Channel Count		
	Device Character Set		
	Device Reset		
	Device Temperature Selector		
	Device Temperature		
	Find Me		
	Device Max Throughput (Kbps)		
Image Format Control	Width Max	Section View Resolution & Set ROI	
	Height Max		
	Region Selector		
	Width		
	Height		
	Offset X		
	Offset Y		
	Reverse X	Section Set Image Reverse	
	Reverse Y		
	Pixel Format	Section Set Pixel Format	
	Pixel Size		
	Test Pattern Generator Selector	Section Set Test Pattern	
	Test Pattern		
	Binning Selector	Section Set Binning	
	Binning Horizontal		

	Binning Vertical		
	Decimation Horizontal	Section Set Decimation	
	Decimation Vertical		
	Embedded Image Info Selector	Section Set Embedded	
	Frame Spec Info	Information in Image	
Acquisition Control	Acquisition Mode	Section Set Frame Rate	
	Acquisition Stop		
	Acquisition Burst Frame Count		
	Acquisition Frame Rate (Fps)		
	Acquisition Frame Rate Control Enable		
	Resulting Frame Rate (Fps)		
	Trigger Selector	Section External Trigger Mode	
	Trigger Mode		
	Trigger Software		
	Trigger Source		
	Trigger Activation		
	Trigger Delay (μs)		
	Trigger Cache Enable		
	Sensor Shutter Mode	Section Sensor Shutter Mode	
	Exposure Mode	Section Set Exposure Time	
	Exposure Time Mode	Mode & Set Exposure Auto	
	Exposure Time (μs)		
	Exposure Auto		
	Auto Exposure Time Lower Limit (μs)		
	Auto Exposure Time Upper Limit (μs)		
	HDR Enable	Section Set HDR	
	HDR Selector		
	HDR Shutter (μs)		

	HDR Gain	
Analog Control	Gain (dB)	Section Set Gain
	Gain Auto	
	Auto Gain Lower Limit (dB)	
	Auto Gain Upper Limit (dB)	
	Digital Shift	
	Digital Shift Enable	
	Brightness	Section Set Brightness
	Black Level	Section Set Black Level
	Black Level Enable	
	Balance White Auto	Section Set White Balance
	AWB Color Temperature Mode	
	Balance Ratio Selector	
	Balance Ratio	
	Gamma	Section Set Gamma Correction
	Gamma Selector	
	Gamma Enable	
	Sharpness Enable	Section Set Sharpness
	Sharpness	
	Hue	Section Set Hue and Saturation
	Hue Enable	
	Saturation	
	Saturation Enable	
	Channel Correct Mode	Section Set Channel Correct Mode
	Fan Open Threshold	Section Set Fan
	Auto Function AOI Selector	Section Set AOI
	Auto Function AOI Width	
	Auto Function AOI Height	

	Auto Function AOI Offset X	
	Auto Function AOI Offset Y	
	Auto Function AOI Usage	
	Intensity	
	Auto Function AOI Usage White Balance	
Color	Color Transformation Selector	Section Set Color
Transformation Control	Color Transformation Enable	Transformation Control
Control	Color Transformation Value Selector	
	Color Transformation Value	
LUT Control	LUT Selector	Section Set LUT
	LUT Enable	
	LUT Index	
	LUT Value	
Shading	NUC Enable	Section Set Shading Correction
Correction	FPNC Enable	
	PRNUC Enable	
	Shading Selector	
	Activate Shading	
	LSC Enable	
Digital IO Control	Line Selector	Section I/O Output
	Line Mode	
	Line Inverter	
	Line Status	
	Line Status All	
	Line Debouncer Time (μs)	
	Line Source	
	Strobe Enable	]
	Strobe Line Duration (μs)	]

	Strobe Line Delay (μs)	
	Strobe Line Pre Delay (μs)	
Action Control	Action Unconditional Mode	Section Set Action Command
	Action Device Key	
	Action Queue Size	
	Action Selector	
	Action Group Mask	
	Action Group Key	
Counter And Timer	Counter Selector	Section Set Counter Trigger
Control	Counter Event Source	
	Counter Reset Source	
	Counter Reset	
	Counter Value	
	Counter Current Value	
File Access Control	File Selector	Section File Access Control
	File Operation Selector	
	File Operation Execute	
	File Open Mode	
	File Operation Status	
	File Operation Result	
	File Size (B)	
Event Control	Event Selector	Section Set Event Control
	Event Notification	
Chunk Data Control	Chunk Mode Active	Section Embedded Information
	Chunk Selector	in Image
	Chunk Enable	
Transport Layer	Paylode Size (B)	Section Transport Layer Control
Control	GEV Version Major	

GEV Version Minor
GEV Device Mode Is Big
Endian
GEV Device Mode Character Set
GEV Interface Selector
GEV MAC Address
GEV Supported Option
Selector
GEV Supported Option
GEV Current IP Configuration
GEV Current IP Configuration
Persistent IP
DEV PAUSE Frame Reception
GEV Current IP Address
GEV Current Subnet Mask
GEV Current Default Gateway
GEV First URL
GEV Second URL
GEV Number Of Interfaces
GEV Persistent IP Address
GEV Persistent Subnet Mask
GEV Persistent Default
GEV Link Speed
GEV Message Channel Count
GEV Stream Channel Count
GEV Heartbeat Timeout (ms)
GEV Heartbeat Disable
GEV Timestamp Tick
Frequency (Hz)

	Timestamp Control Latch	
	Timestamp Control Reset	
	Timestamp Control Latch	
	Timestamp Value	
	GEV CCP	
	GEV MCP Host Port	
	GEV MCDA	
	GEV MCTT (ms)	
	GEV MCRC	
	GEV MCSP	
	GEV Stream Channel Selector	
	GEV SCP Interface Index	
	GEV SCP Host Port	
	GEV SCP Direction	
	GEV SCPS Fire Test Packet	
	GEV SCPS Do Not Fragment	
	GEV SCPS Big Endian	
	GEV SCPS Packet Size (B)	
	GEV SCPD	
	GEV SCDA	
	GEV SCSP	
	Gev IEEE 1588	
	Gev GVSP Extended ID Mode	
User Set Control	User Set Current	Section Save and Load User Set
	User Set Selector	
	User Set Load	
	User Set Save	
	User Set Default	

